

Playmates®

PLAYMATES TOYS INC.

## LIMITED 90 DAY WARRANTY

Playmates Toys Inc. warrants to the original consumer purchaser that your Corky doll is free from any defects in materials or workmanship for a period of 90 days from the date of purchase. If any defect is discovered within the warranty period, Playmates Toys Inc. will repair or replace the unit at its option, subject to verification of the defect or malfunction. Purchaser should send the Corky doll, following the directions in the Health Care Plan, to:

**Corky's Care Center**  
2350 Pleasant Ave.  
Hamilton, Ohio 45015

This warranty does not apply to defects resulting from abuse, alteration, or unreasonable use of the doll. Any applicable implied warranty including warranties of merchantability and fitness are hereby limited to 90 days from date of purchase.

Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are excluded. Some states do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

Playmates®

Corky

## HEALTH CARE PLAN

If you should have any problems with Corky, call this toll-free number for Corky's Care Center: **1-800-262-5511** (in Ohio 1-800-624-3511). Many times a problem can be solved with a telephone call.

If Corky's problem can not be fixed at home, we will fix him immediately at Corky's Care Center.

1. Remove Corky's clothing and pack him in a strong carton.
2. Enclose a note with:
  - a. Your name, address, and telephone number.
  - b. Proof of the date of purchase.
  - c. A description of the problem.
  - d. His Health Care Card number that you received after you sent in his warranty card. If you have not sent in the warranty card, send it now with Corky.
3. If you have had your Corky more than 90 days but less than 2 years, include a check or money order for **\$19.95** to cover repairs, return postage, insurance and packing.
4. Attach proper postage to the carton or use the pre-paid label you received after you sent in the warranty card. Mail the carton to:  
**CORKY'S CARE CENTER**  
2350 Pleasant Ave.  
Hamilton, Ohio 45015
5. Corky will return in a hospital gown with an I.D. bracelet, and a Health Certificate.

NOTE TO PARENTS: PLEASE READ THIS FOLDER AND MAKE SURE YOUR CHILDREN KNOW HOW TO TAKE CARE OF CORKY. THEN SEND IN THE WARRANTY CARD AND KEEP THIS FOLDER FOR REFERENCE.

Corky

## SERVICE AGREEMENT


If your Corky doll requires service after the 90 days limited warranty period, Playmates Toys Inc. will service the doll upon receipt, postage prepaid, with your check or money order in the sum of **\$19.95** to cover the cost of repair, return postage, insurance and packing) and proof of the date of purchase.

This Service Agreement does not apply to defects from abuse, alteration or unreasonable use and does not apply to a doll which requires service two years after the date of purchase.

## GETTING TO KNOW CORKY®

1.

Put in his batteries (carefully).



Pull up Corky's shirt and lift the flap to open the battery compartment. Install 4 C-batteries and 1 9-volt battery exactly as shown in the diagram. **Be sure to use alkaline batteries.**

2.


Insert his cassette (slowly).



Corky comes with an instruction tape. Play this first for operating and safety tips. To change the tape, push the red button to open the door. Be careful not to force the door to open too far. Remove the tape and slip in a new tape, making sure the exposed tape is at the top. Close the door.

3.

Press the buttons (gently).



Press the **green** play button to hear Corky's tape. Press the **red** stop/eject button to stop the tape and open the door. Press the **blue** rewind button to hear something again. Press the **yellow** fast forward button to skip ahead. Adjust the volume by turning the volume wheel. **Note:** Any cassette can be played in Corky, but his mouth moves best with his own tapes.

## HEALTH TIPS



Keep Corky in a cool dry place when you aren't playing with him. He doesn't like **DIRT, HEAT, and WATER.**

- Don't use sharp objects, pens, or pencils near Corky.
- Never put him in water.
- Clean his tape player once a month. Ask your parents to help you. You can buy a cleaning kit at a store that sells tapes. Cleaning his tape player will make Corky and his tapes last longer.
- Remove his batteries if you won't be playing with Corky for a long time.

## GROOMING TIPS



Corky's hair and skin can be cleaned with mild soap and a damp cloth. Never put him in water. His hair can be brushed and styled, but do not use a hair dryer, curling iron, or hair spray. Corky's clothes can be washed by hand with mild soap and air dried.

## THE DOCTOR SAYS



- If Corky's voice is distorted, the tape stops, or his mouth won't move, change all 4 of his C-batteries.
- If he is too quiet, adjust the volume wheel. If he is still too quiet, change his 9-volt battery. **USE ALKALINE BATTERIES ONLY.**
- If he won't work at all, make sure his tape is not at the end, the tape door is closed, and the green play button is pressed down. You can play one side of his instruction tape in any regular cassette tape player for more tips.
- **IMPORTANT**—Do not leave the blue (rewind) or the yellow (fast forward) buttons depressed. The motor will continue to run after the tape stops, causing the batteries to run down quickly.





**MAIL THIS WARRANTY CARD TODAY**

CUT ALONG PERFORATIONS

**PLAYMATES TOYS, INC.**

**Corky**

**WARRANTY CARD**

Complete and return this card to enter your Corky into Corky's Health Care Plan. **You will receive a personalized I.D. card and prepaid postage label that you can use if you should need to send Corky to the Health Center.**

Child's Name \_\_\_\_\_ ☐ girl ☐ boy

Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_

Telephone: ( \_\_\_\_\_ ) \_\_\_\_\_

Age of Child: \_\_\_\_\_ Date Purchased: \_\_\_\_\_

Please take a moment to answer these questions. We want to make toys that satisfy children and parents, and your answers will help us.

1. Comments about Corky: \_\_\_\_\_

2. What accessories would you like to be able to buy for Corky?

3. Was Corky purchased as a ☐ Birthday gift ☐ Christmas or

Chanukah gift ☐ Other: \_\_\_\_\_

4. How did you hear about Corky? ☐ TV ☐ Friends ☐ Display

☐ Other: \_\_\_\_\_

5. What features are most important to you when you shop for toys?

CUT ALONG PERFORATIONS